#### TEAM 20



#### TEAM MEMBERS

- احمد محمد محمد فرغلي •
- ایهاب راشد مسعود رضوان •
- عبد الرحمن ماهر •
- ایه حسني سعید •
- يوسف خليفة •

#### LINKS

- RAW DATA(10 Files):https://www.ebi.ac.uk/pride/archive/projects/PXD029586
- Fasta file:
- >sp | Q99527 | GPER1\_HUMAN G-protein coupled estrogen receptor 1 OS=Homo sapiens OX=9606 GN=GPER1 PE=1 SV=1
- MDVTSQARGVGLEMYPGTAQPAAPNTTSPELNLSHPLLGTALANGTGELSEHQQYVIGLF
- LSCLYTIFLFPIGFVGNILILVVNISFREKMTIPDLYFINLAVADLILVADSLIEVFNLH
- ERYYDIAVLCTFMSLFLQVNMYSSVFFLTWMSFDRYIALARAMRCSLFRTKHHARLSCGL
- IWMASVSATLVPFTAVHLQHTDEACFCFADVREVQWLEVTLGFIVPFAIIGLCYSLIVRV
- LVRAHRHRGLRPRRQKALRMILAVVLVFFVCWLPENVFISVHLLQRTQPGAAPCKQSFRH
- AHPLTGHIVNLAAFSNSCLNPLIYSFLGETFRDKLRLYIEQKTNLPALNRFCHAALKAVI
- PDSTEQSDVRFSSAV

#### CODE

```
In [48]: from pyopenms import *
         import matplotlib.pyplot as plt
         def mirror_plot(obs_mz, obs_int, theo_mz, theo_int, title):
           obs_int = [element / max(obs_int) for element in obs_int] # relative intenstiy
           theo_int = [element * -1 for element in theo_int] # invert the intensity for the mirror plot
           plt.figure(figsize=(12, 8))
           plt.bar(obs_mz, obs_int, width=3.0)
           plt.bar(theo_mz, theo_int, width=3.0)
           plt.title(title)
           plt.ylabel('intensity')
           plt.xlabel('m/z')
           plt.show()
         protein_ids = []
         peptide_ids = []
         SimpleSearchEngineAlgorithm().search("cc3.mzML", "cancer.fasta", protein_ids, peptide_ids)
         for peptide_id in peptide_ids:
             print ("Peptide Index m/z:", peptide_id.getMetaValue("scan_index"))
             for hit in peptide_id.getHits():
                 print(" - Peptide hit sequence:", hit.getSequence())
                 string= hit.getSequence().toString()
                 tsg = TheoreticalSpectrumGenerator()
                 theo_spec = MSSpectrum()
                 p = Param()
                 p.setValue("add_y_ions", "true")
p.setValue("add_b_ions", "true")
p.setValue("add_metainfo", "true")
                 tsg.setParameters(p)
                 peptide = AASequence.fromString(hit.getSequence().toString())
                 tsg.getSpectrum(theo_spec, peptide, 1, 2)
                 # Iterate over annotated ions and their masses
                 print("Spectrum 1 of", peptide, "has", theo_spec.size(), "peaks.")
                 for ion, peak in zip(theo_spec.getStringDataArrays()[0], theo_spec):
                     print(ion.decode(), "is generated at m/z", peak.getMZ())
                 exp = MSExperiment()
                 MzMLFile().load("cc3.mzML", exp)
                 spectra = exp.getSpectrum(peptide_id.getMetaValue("scan_index"))
                 alignment = []
                 spa = SpectrumAlignment()
                 p = spa.getParameters()
                 p.setValue("tolerance", 0.5)
                 p.setValue("is_relative_tolerance", "false")
                 spa.setParameters(p)
                # align both spectra
                 spa.getSpectrumAlignment(alignment, theo_spec, spectra)
                 # Print matching ions and mz from theoretical spectrum
                 print("Number of matched peaks: " + str(len(alignment)))
                 print("ion\ttheo. m/z\tobserved m/z")
                 for theo_idx, obs_idx in alignment:
                      ion_name = theo_spec.getStringDataArrays()[0][theo_idx].decode()
                      ion_charge = theo_spec.getIntegerDataArrays()[0][theo_idx]
                      print(ion_name + "\t" + str(ion_charge) + "\t"
                            + str(theo_spec[theo_idx].getMZ())
                            + "\t" + str(spectra[obs_idx].getMZ()))
                 theo_mz, theo_int, obs_mz, obs_int = [], [], [], []
                 for theo_idx, obs_idx in alignment:
                      theo_mz.append(theo_spec[theo_idx].getMZ())
                      theo_int.append(theo_spec[theo_idx].getIntensity())
                      obs_mz.append(spectra[obs_idx].getMZ())
                      obs_int.append(spectra[obs_idx].getIntensity())
                 title = f'{string},{peptide_id.getMetaValue("scan_index")}'
                  flag=False
                 for i in obs_int:
                     if(i>0):
                          flag=True
                         break
                 if(flag==True):
                    mirror_plot(obs_mz, obs_int, theo_mz, theo_int, title)
                 else:
                     flag=False
```

#### MIRROR PLOT FUNCTION

```
import matplotlib.pyplot as plt
def mirror_plot(obs_mz, obs_int, theo_mz, theo_int, title):
    obs_int = [element / max(obs_int) for element in obs_int] # relative intenstiv
    theo_int = [element * -1 for element in theo_int] # invert the intensity for the mirror plot
    plt.figure(figsize=(12, 8))
    plt.bar(obs_mz, obs_int, width=3.0)
    plt.bar(theo_mz, theo_int, width=3.0)
    plt.title(title)
    plt.ylabel('intensity')
    plt.xlabel('m/z')
    plt.show()
```


#### SIMPLE SEARCH ENGINE


```
Peptide Index m/z: 11517
- Peptide hit sequence: YYDIAVLC(Carbamidomethyl)TFMSLFLOVNM(Oxidation)YSSVFFLTWM(Oxidation)SFDR
Spectrum 1 of YYDIAVLC(Carbamidomethyl)TFMSLFLOVNM(Oxidation)YSSVFFLTWM(Oxidation)SFDR has 126 peaks.
y1++ is generated at m/z 88.06311469007102
v2++ is generated at m/z 145.576586769821
b2++ is generated at m/z 164.07060575387098
v1+ is generated at m/z 175,118952913371
v3++ is generated at m/z 219.110793913371
b3++ is generated at m/z 221.58407783362097
v4++ is generated at m/z 262.62680849312096
b4++ is generated at m/z 278.12611000907094
v2+ is generated at m/z 290.14589707287104
b5++ is generated at m/z 313.64466708882094
b2+ is generated at m/z 327.133935040971
y5++ is generated at m/z 336.14450850167094
b6++ is generated at m/z 363.17887423237096
b7++ is generated at m/z 419.72090640782096
y6++ is generated at m/z 429.18416516117094
v3+ is generated at m/z 437.214311359971
b3+ is generated at m/z 442.16087920047096
y7++ is generated at m/z 479.7080047728209
b8++ is generated at m/z 499.736230900421
y4+ is generated at m/z 524.246340519471
y8++ is generated at m/z 536.2500369482709
b9++ is generated at m/z 550.260070512071
b4+ is generated at m/z 555.244943551371
y9++ is generated at m/z 609.7842440918209
b10++ is generated at m/z 623.794277655621
b5+ is generated at m/z 626.282057710871
y5+ is generated at m/z 671.2817405365709
y10++ is generated at m/z 683.318451235371
b11++ is generated at m/z 689.314520164171
b6+ is generated at m/z 725.350471997971
b12++ is generated at m/z 732.830534743921
```


#### EXPERIMENNTAL AND ALIGN PEAKS


```
# Iterate over annotated ions and their masses
print("Spectrum 1 of", peptide, "has", theo spec.size(), "peaks.")
for ion, peak in zip(theo spec.getStringDataArrays()[0], theo spec):
    print(ion.decode(), "is generated at m/z", peak.getMZ())
exp = MSExperiment()
MzMLFile().load("cc3.mzML", exp)
spectra = exp.getSpectrum(peptide id.getMetaValue("scan index"))
alignment = []
spa = SpectrumAlignment()
p = spa.getParameters()
p.setValue("tolerance", 0.5)
p.setValue("is relative tolerance", "false")
spa.setParameters(p)
# align both spectra
spa.getSpectrumAlignment(alignment, theo spec, spectra)
# Print matching ions and mz from theoretical spectrum
print("Number of matched peaks: " + str(len(alignment)))
print("ion\ttheo. m/z\tobserved m/z")
for theo idx, obs idx in alignment:
    ion_name = theo_spec.getStringDataArrays()[0][theo_idx].decode()
    ion_charge = theo_spec.getIntegerDataArrays()[0][theo_idx]
    print(ion name + "\t" + str(ion charge) + "\t"
          + str(theo spec[theo idx].getMZ())
          + "\t" + str(spectra[obs idx].getMZ()))
theo mz, theo int, obs mz, obs int = [], [], [], []
for theo idx, obs idx in alignment:
    theo_mz.append(theo_spec[theo_idx].getMZ())
    theo int.append(theo spec[theo idx].getIntensity())
    obs_mz.append(spectra[obs_idx].getMZ())
    obs int.append(spectra[obs idx].getIntensity())
title = f'{string},{peptide id.getMetaValue("scan index")}'
flag=False
for i in obs_int:
    if(i>0):
        flag=True
        break
if(flag==True):
   mirror plot(obs mz, obs int, theo mz, theo int, title)
else:
   flag=False
```

#### RAW FILE 1 (AVIPDSTEQSDVR), (TNLPALNR)













#### RAW FILE 1 (TQPGAAPCK), (AVIPDSTEQSDVR)







## RAW FILE 2 (MDVTSQAR),(TQPGAAPC(CARBAMIDOMETHYL)K)







## RAW FILE3 (AVIPDSTEQSDVR), (TQPGAAPC (CARBAMI DOMETHYL)K)







#### RAW FILE 4 (M(OXIDATION)DVTSQAR),(TQPGAAPC(CARBAMIDOMETHYL)K)







#### RAW FILE 4 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)







### RAW FILE 5 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)







## RAW FILE 5 (AVIPDSTEQSDVR), (TQPGAAPC (CARBAMI DOMETHYL)K)






#### RAW FILE 5 (M(OXIDATION)DVTSQAR),(FC(CARBAMIDOMETHYL)HAALK)







#### RAW FILE 6

(AVIPDSTEQSDVR), (TQPGAAPC (CARBAMIDOMETHYL)K)







## RAW FILE 6 (TNLPALNR), (FC (CARBAMIDOMETHYL) HAALK)




# RAW FILE 6 (M(OXIDATION)DVTSQAR),(FC(CARBAMIDOMETHYL)HAALK)







# RAW FILE 7 (TQPGAAPC (CARBAMIDOMETHYL)K), (AVIPDSTEQSDVR)





# RAW FILE 7 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)







#### RAW FILE 7 (M(OXIDATION)DVTSQAR), (FC(CARBAMIDOMETHYL)HAALK)







## RAW FILE 8 (M(OXIDATION)DVTSQAR), (FC(CARBAMIDOMETHYL)HAALK)







## RAW FILE 8 (TQPGAAPC(CARBAMIDOMETHYL)K),(AVIPDSTEQSDVR)







### RAW FILE 8 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)







# RAW FILE 9 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)







### RAW FILE 9 (TQPGAAPC(CARBAMIDOMETHYL)K),(AVIPDSTEQSDVR)







### RAW FILE 9 (M(OXIDATION)DVTSQAR), (FC(CARBAMIDOMETHYL)HAALK)







#### RAW FILE 10 (M(OXIDATION)DVTSQAR),(FC(CARBAMIDOMETHYL)HAALK)





## RAW FILE 10 (TQPGAAPC (CARBAMIDOMETHYL)K), (AVIPDSTEQSDVR)





## RAW FILE 10 (FC(CARBAMIDOMETHYL)HAALK),(TNLPALNR)